

Where can I find the serial number SN of a Huawei fiber optic switch

Article Overview

The serial number of a Huawei fiber optic switch can be found on the physical device label, via CLI commands, or through the web management interface.

Physical Label

The serial number is typically printed on a label attached to the rear, bottom, or side of the switch chassis. For rack-mounted units, the label may be on the side and partially hidden. The serial number is usually a 20-character barcode starting with "21" (e.g., 210235383610C3000006) and is clearly marked as the device SN .

Command-Line Interface (CLI)

You can retrieve the serial number using the switch console, Telnet, or SSH:

- o display esn: Shows the equipment serial number (ESN) of the switch .
- o display elabel slot slot-id: Displays the electronic label information for a specific slot, including the serial number under the BarCode field .
- o display device manufacture-info [slot slot-id]: Provides manufacturing information, including the serial number and manufacturing date. This command is supported in V200R003 and later versions .

Web Management Interface

If the switch has the web NMS enabled:

- o EasyOperation Web System (V200R005 and later): Log in, click Monitor on the toolbar, and view the device information, including the serial number .
- o Classic Web System: Log in, click Device Summary, and check the card information to find the serial number .
- o Navigate to System Management > Device Information in the web GUI to see the serial number field clearly displayed . By using any of these methods, you can accurately locate the serial number for warranty verification, technical support, or network management purposes.

When a user needs after-sales service, the user needs to provide the serial number (SN) or contract number of the device for

Where can I find the serial number SN of a Huawei fiber optic switch

Learn how to perform a Huawei switch warranty check, locate serial numbers, verify support coverage, and ensure network reliability

Serial number ("SN" for short) refers to a product's ID, and is also known as the machine number, authentication code, and

Check the warranty status of your HUAWEI product. Enter the device serial number to view the warranty period and rights.

Displaying the Device Serial Number Context Each device has a unique equipment serial number (ESN). When you require technical

Obtaining the Serial Number of a Power Module Log in to the master switch through Telnet or the console interface, and

Method 1: Determine the Device Serial Number by Using a Command Run the display esn command to view the serial number of a

How do I check device serial number? .Please choose a language to see the specific content of your site English Français

Serial number ("S/N" for short) refers to a product's ID, and is also known as the machine number, authentication code, and

Each of your HUAWEI devices have only one corresponding serial number, which we also call SN. Where can you find your device's

The device serial number label is attached to the top of a switch, on the corner closest to the left of the interface side. The removable

Solution Log in to the switch through Telnet or the console interface, and then run the display elabel slot slot-id command (slot-id

HUAWEI SN number is an individual serial number for HUAWEI phones, Laptops, Tablets, Watches and Smart Home. The IMEI

We're sorry but web site doesn't work properly without JavaScript enabled. Please enable it to continue.

Learn about "How do I check the SN of HUAWEI CPE or HUAWEI Mobile WiFi". Find all usage guide,

Where can I find the serial number SN of a Huawei fiber optic switch

troubleshooting tips and

Log in to the device through the web system, and click Monitor on the toolbar to view device information, including the device serial

Web: <https://www.morwarreconst.co.za>

